

# **Technical Bulletin**

### **Preparing Bill Acceptor to accept**

2014 New Series Polymer Banknotes

Date: 2013/12/06

## International Currency Technologies Corp.

Technical Bulletin 2014 New Canadian Polymer Notes	Approved: Richard Yang	Prepared by: Simon Huang Version: ICTA 131206
Purnose		
Due to the new designed of the	new Canadian polymer ban	knotes, all bill
acceptors in the field will	need to complete the sense	or calibration.
Following instructions will give calibration procedures, w	detail information about the hich is required within rece	e download and the ent software

Firmware Version: TS5FJCAA4 (8B06) Support Banknotes: 5(02,06,13)/10(01,05,13)/20(04,12)

amendments.

### Make the connection as following figure: Procedures:

Step1. Use PC download tool to save the latest firmware into FP-001; turn the power on and make sure the programmer's LED L4 is flashing.





Step2. Turn on the power then press RESET/START button on the FP-001. L4 LED must flashing in green.



Step3. Switching to Program and then switching to L3. L3 must lighting in red and L4 flashing in green. (If L4 not flashing, please go back to step1)



Step4. Press RESET/START button to start download firmware.



Step5. L4 LED status during download:

Lighting red -> Out -> Flashing red -> Orange (BA will restart one time after download)









Page - 4 - of 6

Step6. Press RESET/START button when L4 lighting in orange.

Insert the calibration card when BA lighting in green.



**Calibration Direction:** 





#### Attention:

- 1. Please follow the arrow direction to insert the calibration cards.
- 2. Make sure the bill acceptor two times in and out during the calibration process.
- 3. If you do not have the calibration card, please contact ICT America for assistant.

**Contact Information:** 

International Currency Technologies Corporation (HQ) No 24, Alley 38, Lane 91, Neihu Rd., Sec. 1, Taipei City 114, Taiwan, R.O.C. Tel: 886-2-2797-1238 Fax:886-2-2797-1634 E-mail: <u>rma@ictgroup.com.tw</u>

ICT USA Address: 48929 Milmont Dr., Fremont, CA 94538, USA Tel: +1-510-353-0289 Fax: +1-510-353-0399 E-mail: <u>sales@ict-america.com</u>