COM Port Settings

Windows Vista/7

Basic Information

- 1. In Order to use ICT Tools, you must have a COM Port on your computer.
- 2. If not, you would have to purchase a RS232 to USB Converter witch will allow you to use a USB Port on your computer.
- 3. If you do use a RS232 to USB Converter, please follow the manufactures instructions in order to install the drivers. Make sure that after installing drivers that the COM number is changed to COM1. (See below instructions on how to change COM number)

Settings

- 1. To access your COM Port settings on your computer, please follow these steps:
 - a. Go to your start menu.



b. Find Computer and right click and go to properties.



c. Click on Device Manager.



d. Look for Ports in the list.



e. Double click on Ports to drop down another item.



f. Double click on Port Name to bring up Port Properties.

General	Port Settings	Driver	Details	Resources			
and a second	Communicatio	ons Port (Port (COM1)				
	Device type:	Po	Ports (COM & LPT) (Standard port types)				
	Manufacturer	: (S					
	Location:	on	on Intel(R) 82801GB/GR (ICH7 Family) LPC				
Devic	e status						
Inis	aevice is workin	ig prope	ny.			*	

- g. Click on Ports Setting tab on top.
- h. Make sure COM Setting are as follow
 - i. Bits per second 9600
 - ii. Data Bits 8
 - iii. Parity None
 - iv. Stop bits -1
 - v. Flow Control None

Communic	ations Port (C	OM1) P	roperties	×
General	Port Settings	Driver	Details	Resources
		<u>B</u> its pe	er second: <u>D</u> ata bits: <u>P</u> arity: <u>S</u> top bits:	9600
		<u>B</u> o	w control:	vanced
				OK Cancel

If COM Port is not set to (COM1), now is the time to set it:
a. Click on Advance tab in the Port Settings.

- i. Under COM Port number, click on the down arrow and select COM1 as your Port Number.
- ii. Click Ok to close the Advance window.
- iii. Click Ok to close the COM Port window.
- iv. Back in the Device Manager window, if under Ports it says COM1, you can close out the window.
- v. If it does not same COM1, you need to restart your computer to take effect of the new setting. (Depends on Operating System)

Advanced Settings for COM1	-	-				×
♥ Use FIFO buffers (requ Select lower settings to Select higher settings	OK Cancel					
<u>R</u> eceive Buffer: Low (1)	1	1	 Q	High (14)	(14)	<u>D</u> efaults
<u>T</u> ransmit Buffer: Low (1)	1		 — Ģ	High (16)	(16)	
COM Port Number: COM1	•					

3. For all ICT Tools being used, make sure that COM1 in the tool is selected. Having another COM number will give you no communication between your Bill Acceptor and the Tool. (Default setting for all ICT Tools will be COM1)

Troubleshooting

- 1. If there is no communication between Bill Acceptor and Computer, make sure the following are correct:
 - a. Make sure that all connections to computer and Bill Acceptor are secure.
 - b. Make sure that software for other devices that use same COM Port are not running in the background to prevent communication problems.
 - c. If using a RS232 to USB Converter, make sure drivers are installed properly and COM Port is set to COM1.
 - d. Power is applied to Bill Acceptor in order for communication to be accessed.